

Mounting Hint for Sargent & Greenleaf 6280 Series Time Locks

Place the lock washer and flat mounting washer over the base attaching screw and insert the screw through the hole in the base from the inside. Install the plastic spacer over the base attaching screw from the outside of the base. Slide the foam resilient washer over the spacer. To keep all components in place during installation, press the assembly washer over the end of the base attaching screw until it contacts the end of the spacer.

