

Sargent & Greenleaf ASERIES Quickstart Guide for Bank Mode

Revised 6/15/2010



Open Lock



Enter 8 digit code



Enter #



Turn handle

Change Code



Enter 2 2 *



Enter old 2 digit PIN
Enter old 6 digit code
Enter #



Enter same 2 digit PIN
Enter new 6 digit code
Enter #



Enter same 2 digit PIN
Enter new 6 digit code
Enter #

Add User



Enter 7 4 *



Enter 8 digit
Officer code
Enter #



Enter any other
existing 8 digit code
Enter #



Enter new 2 digit PIN
Enter new 6 digit code
Enter #



Enter same 2 digit PIN
Enter same 6 digit code
Enter #

Delete User



Enter 7 4 *



Enter 8 digit
Officer code
Enter #



Enter any other
existing 8 digit code
Enter #



Enter 2 digit PIN
for code to delete
Enter #



Enter same 2 digit PIN
for code to delete
Enter #

Get Audit



Enter 2 8 *



Enter 8 digit
Programmer code
Enter #



Enter 8 digit
cipher code provided
with key
Enter #



Snap key
into receptacle
Amber LED lights



Remove key
after 3 beeps and
green LED flashes

Set Time Delay



Enter 7 4 *



Enter 8 digit
Programmer code
Enter #



Enter 8 digit
Officer or Admin code
Enter #



Enter 0 0 #



Enter time delay
minutes #
Enter time delay
minutes #

Set Opening Window



Enter 7 4 *



Enter 8 digit
Programmer code
Enter #



Enter 8 digit
Officer or Admin code
Enter #



Enter 0 1 #



Enter opening window
minutes #
Enter opening window
minutes #

Sargent & Greenleaf ASERIES Quickstart Guide for Service Mode

Revised 6/15/2010



Open Lock



Snap key
into receptacle



Enter 4 digit PIN and #
Enter 8 digit op code
Enter #



3 beeps and
green LED flashes



Open ATM



Close ATM



Remove key
after 3 beeps and
green LED flashes

Reset Key



Snap key
into receptacle



Enter 4 digit PIN
Enter #



Enter 8 digit op code
Enter #



Amber LED lights



Remove key
after 3 beeps and
green LED flashes

Set Clock Calendar



Snap key
into receptacle



Enter 4 digit PIN and #



Enter 8 digit op code
Enter #



5 beeps and
green LED flashes



Enter time (HHmm) #
—again—
Enter time (HHmm) #



Remove key
after 3 beeps and
green LED flashes

Get Audit



Snap key
into receptacle




Enter 4 digit PIN
Enter #



Enter 8 digit op code
Enter #



Amber LED lights



Remove key
after 3 beeps and
green LED flashes

Add/Revoke Dispatcher



Snap key
into receptacle




Enter 4 digit PIN
Enter #



Enter 8 digit op code
Enter #



Amber LED lights



Remove key
after 3 beeps and
green LED flashes

Program Bank Features




Snap key
into receptacle



Enter 4 digit PIN
Enter #



Enter 8 digit op code
Enter #



Amber LED lights



Remove key
after 3 beeps and
green LED flashes